

Periodic Maintenance Procedures


Rear Brake Lever and Pedal Free Play Adjustment

NOTE

- Since the rear brake lever and pedal free play adjustments affect each other, make them at the same time.

Rear Brake Lever:

- Loosen the knurled locknut [A] and turn the adjuster [B] at the rear brake lever in as far as it will go.
- Tighten the locknut.
- Turn the brake lever adjuster [A] at the rear end of the brake cable until the rear brake lever has the correct amount of play.



Brake Pedal:

- Turn the brake pedal adjuster [B] at the rear end of the brake cable until the brake pedal has the correct amount of play.




- Operate the pedal a few times to see that it returns to its rest position immediately upon release.
- Rotate the rear wheels to check for brake drag.
- Check braking effectiveness.
- ★ If there is any doubt as to the conditions of the brake, check the brake parts for wear or damage.

Suspension

Knuckle Joint Inspection

- Visually inspect the boot [A] of knuckle joint.
- ★ If damage, wear or deterioration is found, replace the knuckle joint.




Radiator

Radiator Removal


⚠ WARNING

The radiator fan is connected directly to the battery. The radiator fan may start even if the ignition switch is off. **NEVER TOUCH THE RADIATOR FAN UNTIL THE RADIATOR FAN CONNECTOR IS DISCONNECTED. TOUCHING THE FAN BEFORE THE CONNECTOR IS DISCONNECTED COULD CAUSE INJURY FROM THE FAN BLADES.**


- Drain the coolant (see Cooling System in the Periodic Maintenance chapter).
- Remove:
 - Front Fender (see Frame chapter)
 - Radiator Cover (see Frame chapter)
 - Radiator Screen Mounting Screws [A]
 - Radiator Screen [B] (With the Shroud [C])



- Remove:
 - Radiator Hoses [A]
 - Radiator Fan Wire Connector [B]
 - Radiator Fan Switch Connectors [C]



- Remove:
 - Radiator Mounting Bolts [A]
 - Radiator [B]



CAUTION

Do not touch the radiator core. This could damage the radiator fins, resulting in loss of cooling efficiency.

Crankshaft / Transmission

TABLE OF CONTENTS

Exploded View	9- 2
Specifications	9- 6
Special Tools and Sealant	9- 8
Crankcase	9- 9
Crankcase Disassembly	9- 9
Crankcase Assembly	9-10
Crankshaft/Connecting Rod	9-13
Crankshaft Removal	9-13
Crankshaft Installation	9-13
Connecting Rod Removal	9-13
Connecting Rod Installation	9-13
Crankshaft/Connecting Rod Cleaning	9-14
Connecting Rod Bend	9-14
Connecting Rod Twist	9-14
Connecting Rod Big End Side Clearance	9-15
Connecting Rod Big End Bearing/Crankpin Wear	9-15
Crankshaft Runout	9-17
Crankshaft Main Bearing/Journal Wear	9-17
Transmission	9-18
Shift Lever Removal	9-18
Shift Lever Installation	9-18
Shift Control Cables Removal	9-19
Shift Control Cables Installation	9-19
Reverse Lock Cable Removal	9-20
Reverse Lock Cable Installation	9-20
Transmission Removal	9-21
Transmission Installation	9-22
Shift Fork Bending	9-24
Shift Fork/Gear and Shifter Groove Wear	9-24
Transmission and Shift Mechanism Inspection	9-25
Ball Bearing, Needle Bearing, and Oil Seal	9-27
Ball and Needle Bearing Replacement	9-27
Ball and Needle Bearing Wear	9-27
Oil Seal Inspection	9-27