

TRIUMPH

DAYTONA 675 / DAYTONA 675 R

from VIN 564948

STREET TRIPLE / STREET TRIPLE R

from VIN 560477

SERVICE MANUAL

INSPEKTIONSHANDBUCH

MANUEL D'ENTRETIEN

MANUALE DI MANUTENZIONE

モーターサイクル整備説明書

MANUAL DE MANTENIMIENTO

Triumph Daytona 675, Daytona 675 R, Street Triple and Street Triple R Motorcycle Service Manual

Part Number 3856909, issue 1, 11.2012

Table of Contents

Introduction	
General Information	1
Scheduled Maintenance	2
Cylinder Head	3
Clutch	4
Crankshaft, Connecting Rods and Pistons	5
Balancer	6
Transmission	7
Lubrication	8
Engine Removal/Refit	9
Fuel System/Engine Management	10
Cooling	11
Front Suspension	12
Rear Suspension	13
Brakes	14
Wheels/Tyres	15
Frame and Bodywork	16
Electrical	17

This page intentionally left blank

Introduction

Table of Contents

How to use this manual	vi
Warnings, Cautions and Notes	vi
Tampering with Noise Control System Prohibited	vii
References	vii
Dimensions	vii
Repairs and Replacements	vii
Force	vii
Edges	vii
Tightening procedure	vii

Introduction

This manual is designed primarily for use by trained technicians in a properly equipped workshop. However, it contains enough detail and basic information to make it useful to the owner who desires to perform his own basic maintenance and repair work. The work can only be carried out if the owner has the necessary hand and special service tools to complete the job.

A basic knowledge of mechanics, including the proper use of tools and workshop procedures is necessary in order to carry out maintenance and repair work satisfactorily. Whenever the owner has insufficient experience or doubts his ability to do the work, an authorised Triumph dealer must undertake all adjustments, maintenance, and repair work.

In order to perform the work efficiently and to avoid costly mistakes, read the text and thoroughly familiarise yourself with procedures before starting work.

All work should be performed with great care and in a clean working area with adequate lighting.

Always use the correct special service tools or equipment specified. Under no circumstances use makeshift tools or equipment since the use of substitutes may adversely affect safe operation.

Where accurate measurements are required, they can only be made using calibrated, precision instruments.

For the duration of the warranty period, an authorised Triumph dealer must perform all repairs and scheduled maintenance.

To maximise the life of your Motorcycle:

- Accurately follow the maintenance requirements of the periodic maintenance chart in the Service Manual.
- Do not allow problems to develop. Investigate unusual noises and changes in the riding characteristics of the motorcycle. Rectify all problems as soon as possible (immediately if safety related).
- Use only genuine Triumph parts as listed in the Parts Catalogue/Parts Microfiche.
- Follow the procedures in this manual carefully and completely. Do not take short cuts.
- Keep complete records of all maintenance and repairs with dates and any new parts installed.
- Use only approved lubricants, as specified in the Owner's Handbook, in the maintenance of the motorcycle.

How to use this manual

To assist in the use of this manual, the section title is given at the top of each page.

Each major section starts with a contents page, listing the information contained in the section.

The individual steps comprising repair operations are to be followed in the sequence in which they appear.


Adjustment and repair operations include reference to service tool numbers and the associated illustration depicts the tool.


Where usage is not obvious, the tool is shown in use.

Adjustment and repair operations also include reference to wear limits, relevant data, torque figures, specialist information and useful assembly details.

Warnings, Cautions and Notes

Particularly important information is presented in the following form:

 Warning
This warning symbol identifies special instructions or procedures which, if not correctly followed, could result in personal injury or loss of life.

 Caution
This caution symbol identifies special instructions or procedures which, if not strictly observed, could result in damage to or destruction of equipment.

Note:

- **This note symbol indicates points of particular interest for more efficient and convenient operation.**

Tampering with Noise Control System Prohibited

Owners are warned that the law may prohibit:

- a) The removal or rendering inoperative by any person other than for purposes of maintenance, repair or replacement, of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use; and
- b) the use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.

References

References to the left-hand or right-hand side given in this manual are made when viewing the motorcycle from the rear.

Operations covered in this manual do not always include reference to testing the motorcycle after repair. It is essential that work is inspected and tested after completion and if necessary a road test of the motorcycle is carried out particularly where safety related items are concerned.

Dimensions

The dimensions quoted are to design engineering specification with service limits where applicable.

During the period of running-in from new, certain adjustments may vary from the specification figures given in this manual. These will be reset by the dealer at the 500 mile/800 km service, and thereafter should be maintained at the figures specified in this manual.

Repairs and Replacements

Before removal and disassembly, thoroughly clean the motorcycle. Any dirt entering the engine or other parts will work as an abrasive and shorten the life of the motorcycle. Particular attention should be paid when installing a new part, that any dust or metal filings are cleared from the immediate area.

Force

Common sense should dictate how much force is necessary in assembly and disassembly. If a part seems especially difficult to remove or install, stop and examine what may be causing the problem. Never lever a component as this will cause damage both to the component itself and to the surface being levered against.

Whenever tapping to aid removal of an item is necessary, tap lightly using a hide or plastic faced mallet.

Edges

Watch for sharp edges, especially during engine disassembly and assembly. Protect the hands with industrial quality gloves.

When replacement parts are required, it is essential that only genuine Triumph parts are used.

Safety features and corrosion prevention treatments embodied in the motorcycle may be impaired if other than genuine Triumph parts are fitted. In certain territories, legislation prohibits the fitting of parts not to the manufacturer's specification.

Tightening procedure

Generally, when installing a part with several bolts, nuts or screws, they should all be started in their holes and tightened to a snug fit, evenly and in a cross pattern. This is to avoid distortion of the part and/or causing gas or oil leakage. Conversely, bolts, nuts, or screws, should all be loosened (in sequence if specified) by about a quarter of a turn and then removed.

Where there is a tightening sequence specified in this Service Manual, the bolts, nuts, or screws must be tightened in the order and by the method indicated.

Torque wrench setting figures given in this Manual must be observed. The torque tools used must be of accurate calibration.

Locking devices, where specified, must be fitted. If the efficiency of a locking device is impaired during removal it must be renewed. This applies particularly to micro-encapsulated fixings which must always be replaced if disturbed. Where necessary, the text in this manual will indicate where such a fixing is used.

This page intentionally left blank



1 General Information

Table of Contents

Ignition System Safety Precautions	1.4
Dangerous Substances	1.4
Third Party Products	1.4
Fluoroelastomers	1.4
Oils	1.5
Health Protection Precautions	1.5
Environmental Protection Precautions	1.6
Brakes	1.6
Safety Instructions	1.7
Jacking and Lifting	1.7
Precautions against Damage	1.7
Coolant	1.7
Cleaning Components	1.7
Lubrication	1.7
Joints and Joint Faces	1.8
Gaskets, O-rings	1.8
Liquid Gasket, Non-permanent Locking Agent	1.8
Screw Threads	1.8
Locking Devices	1.8
Fitting a Split Pin	1.8
Circlips, Retaining Rings	1.8
Self Locking Nuts	1.8
Encapsulated Bolts	1.8
Oil and Grease Seals	1.9
Press	1.9
Ball Bearings	1.9
Chassis Bearing Lubrication	1.9
Metal bushes	1.10
Fuel Handling Precautions	1.11
General	1.11
Petrol - Gasoline	1.11
Fuel Tank Removal	1.11

General Information

Chassis Repairs	1.11
Electrical Precautions	1.12
Battery Disconnecting	1.12
Disciplines	1.12
Electrical Wires	1.13
Electrical Testing	1.13
Ohm's Law	1.13
Basic Electrical Circuits	1.13
Circuit Diagrams	1.14
Glossary of Circuit Diagram Symbols	1.14
Tracing Circuits	1.16
To Check Continuity:	1.16
To Measure Voltage:	1.17
Splices	1.17
CAN (Controller Area Networking)	1.18
Alternator/Charging System	1.19
Diagnosis - Charging Circuit	1.19
Starting Circuit	1.20
General Fault Finding - Starter Motor and Relay	1.20
Diagnosis - Starter Circuit	1.21
Inspection	1.22
Replacement Parts	1.22
Service Data	1.22
Specification	1.22
Service Tools and Garage Equipment	1.23
Special Service Tools	1.23
Engine	1.29
Cylinder Head & Valves	1.30
Camshafts	1.31
Clutch/Primary Drive	1.32
Pistons	1.32
Crankshaft	1.33
Transmission	1.33
Final Drive	1.34
Lubrication	1.34
Ignition System	1.34
Connecting Rods	1.35
Fuel System	1.35
Coolant System	1.35
Front Suspension - all models except Daytona 675 R	1.35
Front Suspension - Daytona 675 R only)	1.36
Rear Suspension - all models except Daytona 675 R	1.36
Rear Suspension - Daytona 675 R only	1.36
Fuel Injection System	1.36
Emissions Controls	1.36
Brakes	1.37
Wheels and Tyres	1.38

Frame	138
Electrical Equipment	138
Torque Wrench Settings	139
Cylinder Head Area	139
Clutch	139
Crankshaft , Crankcase and Sprag	140
Engine Covers	140
Transmission	141
Lubrication System	142
Final Drive	142
Cooling System	143
Fuel System, Exhaust System and Airbox	144
Fuel System, Exhaust System and Airbox (continued)	145
Rear Suspension	145
Front Suspension	146
Wheels	146
Front Brakes	147
Rear Brakes	148
ABS System	148
Frame, Footrests, Control Plates and Engine Mountings	149
Electrical	150
Bodywork	151
Bodywork - Continued	152
Clutch Cable Routing - Daytona 675 and Daytona 675 R	153
Clutch Cable Routing - Street Triple and Street Triple R	154
Throttle Cable Routing - Daytona 675 and Daytona 675 R	155
Throttle Cable Routing - Street Triple and Street Triple R	156
Main Wiring Harness Routing - Daytona 675 and Daytona 675 R	157
Main Wiring Harness Routing - Street Triple and Street Triple R	158
Rear Light Harness Routing	159
Front Brake Hose Routing - Daytona 675 and Daytona 675 R	160
Front Brake Hose Routing - Street Triple	161
Front Brake Hose Routing - Street Triple R	162
Rear Brake Hose Routing	163
ABS Brake Hose Routing - Street Triple R shown	164
Fuel Tank Breather Hose Routing - Daytona 675 and Daytona 675 R	165
Fuel Tank Breather Hose Routing - Street Triple and Street Triple R	166
Fuel Tank Breather Hose Routing - Models with Evaporative Emissions	167