





UTSKJUTSCYLINDER
BOOM EXTENSION CYLINDER
SCHUBSTÜCKZYLINDER

200
1
9906 7

Pos Fig Teil	Ant Qty Anz	Best.nr Order.nr Best.nr	Benämning	Description	Benennung	Anm. Notes Anm.
-	1	361 6819	Utskjutscylinder	Extension cylinder	Schubstückzylinder	
1	1	983 9313	*Lasthållningsventil	*Load holding valve	*Lasthalteventil	
2	2	982 8745	*Lagerbussning	*Bearing bushing	*Lagerbuchse	
3	1	361 6771	*Kolvstångshuvud	*Piston with head	*Kolbenstangenkopf	
4	1	361 6851	*Kägla	*Cone	*Kegel	
5	1	996 2859	*Bussning	*Bushing	*Buchse	
6	1	361 6827	*Cylindertopp	*Cylinder head	*Zylinderkopf	
7	1	356 1488	*Låsring	*Retaining ring	*Sicherungsring	
8	1	363 0218	*Kolvstång	*Piston rod	*Kolbenstange	
9	1	363 0226	*Rör	*Pipe	*Rohr	
10	1	982 8958	*Styrring	*Guide ring	*Führungsring	
11	1	361 6860	*Packbox	*Stuffing box	*Packbuchse	
12	1	362 2096	*Kolv	*Piston	*Kolben	
13	1	361 6941	*Mantelrör	*Cylinder tube	*Mantelrohr	
14	1	983 9305	*Lasthållningsventil	*Load holding valve	*Lasthalteventil	
-	1	330 1583	Packningssats	Packing set	Dichtungssatz	
16	1		Ing. i P-sats:	Incl. in P-Set:	Geh. zum D-Satz:	
17	1		*O-ring	*O-ring	*O-ring	
18	1		*Stödring	*Support ring	*Stützring	
19	1		*Avstrykare	*Scraper	*Abstreifer	
20	2		*Tättring	*Seal ring	*Dichtungsring	
21	1		*O-ring	*O-ring	*O-ring	
22	1		*Stödring	*Support ring	*Stützring	
23	1		*Tättring	*Seal ring	*Dichtungsring	
24	2		*O-ring	*O-ring	*O-ring	
24	2		*Stödring	*Support ring	*Stützring	
			I pos 1;14 ingår	In fig 1;14 incl	Teil 1;14 inkl.	
25	1	995 0940	*O-ring	*O-ring	*O-ring	
26	1	983 3846	*O-ring	*O-ring	*O-ring	
27	2	983 3862	*Stödring	*Support ring	*Stützring	
28	1	983 3854	*Stödring	*Support ring	*Stützring	
29	1	982 8222	*O-ring	*O-ring	*O-ring	

