

OP. 55 440 08
POWER SHUTTLE ELECTRONIC
CONTROL UNIT**Removal****CAUTION**


Handle all parts carefully.
Do not put your hands or fingers between parts.
Wear suitable safety clothing - safety goggles, gloves
and shoes.

1. Carry out operation **55 418 10** Multiple indicator panel, only removal (see page 2).
2. Unscrew the retaining screws and remove the Power Shuttle control center (1) from the support, disconnect the dashboard electrical connections and remove the control center.

Installation**CAUTION**

Always use appropriate tools to align fixing holes.
NEVER USE FINGERS OR HANDS.

- Connect the connections to the control center and secure to the support using the screws.
- Carry out operation **55 418 10** indicator panel installation.



OP. 55 510 20
FUSEBOX REPLACEMENT



CAUTION



Handle all parts carefully.
 Do not put your hands or fingers between parts.
 Wear suitable safety clothing - safety goggles, gloves
 and shoes.

Removal

1. Remove the cover (1) on the fuse box.
2. Remove the retaining screws (1) and remove the fuse box.

Installation




CAUTION




Always use appropriate tools to align fixing holes.
NEVER USE FINGERS OR HANDS.

- Position and secure the fuse box.
- Install the cover on the fuse box.



4




5

OP. 55 510 22**FUSES****Replacement****CAUTION**

Handle all parts carefully.
Do not put your hands or fingers between parts.
Wear suitable safety clothing - safety goggles, gloves and shoes.

1. Remove the cover (1) on the fuse box.
2. Replace the faulty fuse.
3. Refit the cover on the fuse box.



6

OP. 55 510 22**RELAY****Replacement****CAUTION**


Handle all parts carefully.
Do not put your hands or fingers between parts.
Wear suitable safety clothing - safety goggles, gloves and shoes.

Proceed as follows.

1. Carry out operation **55 418 10** Multiple indicator panel, only removal (see page 2).
2. Replace the faulty relay.

**CAUTION**

Always use appropriate tools to align fixing holes.
NEVER USE FINGERS OR HANDS.



7

3. Carry out operation **55 418 10** indicator panel installation.

